10ft Round Offset Umbrella with T Base

Assembly and User Manual

ITEM: UMB-990880



NOTE: The schematics in this manual are for assembly and operation illustration only. They may differ from the umbrella's actual appearance.

www.atleisure.com
ATLANTA, GEORGIA
Customer Service Toll Free 1-855-880-7205
Monday through Friday from 8:00am-5:00pm
(Eastern Time)

If you have any questions, problems or need additional parts please **do not return** to the place of purchase. Contact our customer service department toll free at **1-855-880-7205** or email us at **customerservice@atleisure.com**

2. Package Contents |



PART	DESCRIPTION	QTY(PC)
C	Lower Cross Leg (with bolts and washers)	1
D	Upper Cross Leg (with bolts and washers)	1
F	Holder Pole (with control knobs)	1
UAS	Canopy (on the umbrella frame)	1
N	Umbrella Frame (with canopy and holder pole ring)	1

| Replacement Parts (cont'd) 11.

No.	Description	Qty.	Re-order No.	No.	Description	Qty.	Re-order No.
C	Lower Cross Leg	1	#01441	19	Long Main Arm	1pc	#01454
D	Upper Cross Leg	1	#01442	20	Decorative Canopy Cap	1pc	#01455
F	Holder Pole (with control knobs)	1	#01443	21	Upper Rib Holder	1pc	#01456
GG	Bolt	4	#00372	22	Long Rib	5pcs	#01457
H	Washer	4	#00373	23	Connector	5pcs	#01458
7	Crank Assy	1	#01444	24	Rib Holder Support Bar	1pc	#01459
8	Lever clamp w/ button	1pc	#01445				
9	Main Short Rib Bracket	1pc	#01446				
10	Main Short Rib	1pc	#01447	27	Lower Rib Holder	1pc	#01456
11	Glide Handle Housing	1pc	#01448	28	Lower Rib Holder Cap	1pc	#01457
12	Stop Pin	2pcs	S12-S	29	Control Knob	2pcs	S29
13	Rope	1pc	#00415	30	Holder Pole Ring	1pc	#01458
14	Main Pole Pulley	1pc	#01449	31	Upper Rib Holder Pulley	1pc	#01459
15	Pole Top Decorative Cap	1pc	#01450				
16	Top Collar	1pc	#01451				
17	Short Main Arm	1pc	#01452				
18	Main Bracket	1pc	#01453	UAS	Canopy, Olefin	1	UAS-990880 Soft Gold #149

10. Replacement Parts |



| Hardware Contents 3.

PART	PICTURE	DESCRIPTION	QUANTITY
GG		Hex Bolt M10-1.5x20 A2-70	4pcs (Temporarily attached under the cross legs)
HH		Flat Washer M10 A2-70	4pcs (Temporarily attached under the cross legs)

PREPARATION
Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and diagram above. If any part is missing or damaged, do not attempt to assemble the product or return to the place of purchase. Contact our customer service toll free at **1-855-880-7205** for replacement parts or further instructions.

Tools Required for Assembly: Open end wrench or adjustable wrench / Phillips screwdriver (Not included)

Remove all protective materials. Be careful not to throw away small parts such as bolts, washers, etc. that may be wrapped in the protective materials.



Fig. 1

Step 1. Unscrew the Bolts (GG) and Washers (HH) under the cross legs (C and D) as shown in Fig. 1 and put them aside for use in step 3.



Fig. 2

Step 2. Place Lower Cross Leg (C) on the ground, line up notches and place Upper Cross Leg (D) cross over the Lower Cross Leg (C) as shown in Fig.2.



Fig. 3

Step 3. Attach the Holder Pole (F) to the base by using the Bolts (GG) and Washers (HH) from step 1 as shown in Fig. 3. Hand tighten only. Adjust the Holder Pole (F) to be sure it is positioned correctly on the base. Finally tighten all bolts. Be careful not to over tighten.



Fig. 4

Step 4. Finished

90–DAY WARRANTY

This product is covered under a manufacturer's 90-day warranty from date of purchase against defects in materials and workmanship. This warranty does not cover damage due to neglect, abuse or weather related damage. For full warranty disclosure, email us at **customerservice@atleisure.com.**

HOW TO FILE A CLAIM

If you are within your warranty, to file a claim you must have your receipt and pictures of your damaged umbrella. Email information to ATLeisure at **customerservice@atleisure.com**.

8. Warnings |

1. D not use this umbrella during periods of high wind and rain. Failure to do so may result in personal injury and/or property damage.

2. Be sure to secure and/or weight the base of the umbrella.

3. Always take the umbrella down when not in use.

4. Placement of the umbrella over or near a swimming pool can cause premature fading of the canopy. This is not covered under our warranty.

5. To prevent damage to the canopy, open the umbrella facing the opposite direction that the wind is blowing.

CANOPY CARE INSTRUCTIONS:
Simply clean the umbrella canopy with a soft brush and mild detergent!
Do not machine wash.
Do not iron.
Air dry the canopy thoroughly before storing for extended periods of time.
Make sure the canopy is completely open during drying process to prevent shrinkage.

| Assembly Instructions (cont'd) 5.



Fig. 5

Step 5. Insert the main pole of the Umbrella Frame with Canopy (N) into the Holder Pole (F), slide the Holder Pole Ring onto the Holder Pole (F) at same time, until the lower fixed stop pin sits on the Holder Pole Ring as shown in Fig. 5. Tighten the two control knobs (from Step 3) into the Holder Pole (F) to secure the umbrella as shown in Fig. 5.

Step 6. Use appropriate anchors to permanently attach base to your wooden deck or concrete patio or use patio stones or offset umbrella base (sold separately) to weight down the umbrella base.

Contact our customer service department toll free at **1-855-880-7205** or email us at **customerservice@atleisure.com**



Fig. 6



Fig. 7

Step 1. Unfasten the storage straps around the canopy as shown in Fig. 6

Step 2. To open the umbrella, turn the crank handle in the open direction, pull up the Lever clamp, slide the glide handle up along the pole. Push down the Lever clamp when the desired tilting anglehas been achieved. (The higher the glide handle, the less the tilting angle. See Fig. 7 for the definition of the Tilting angle). To fully open the canopy, continue to turn the crank handle in the open direction until the lower center hub reaches the end of the support pole and the canopy has the proper tension.

If the crank becomes too hard to crank, check to see if the rope has come off the pulley. If you continue to turn the crank, the rope could break.
Contact our customer service toll free at **1-855-880-7205** for further assistance.



Fig. 8

Step 3. The umbrella has a unique design that moves the pole out of your way and off to the side. The multiple position canopy can rotate 360°around the axis of the main pole to offer the shade on your expected area around the umbrella as shown in Fig. 8.